

## Combination Key Functions

Key Combination	Windows System	MAC System
FN+ESC (long press)	Restore factory settings	Restore factory settings
FN+Q	RGB brightness up	RGB brightness up
FN+A	RGB brightness down	RGB brightness down
FN+W	RGB effect switch forward	RGB effect switch forward
FN+S	RGB effect switch backward	RGB effect switch backward
FN+E	RGB color switch forward	RGB color switch forward
FN+D	RGB color switch backward	RGB color switch backward
FN+T	RGB effect speed up	RGB effect speed up
FN+Y	RGB effect speed down	RGB effect speed down
FN+M (long press)	Switch to MAC OS mode	Switch to WINDOWS mode
FN+Tab	Quick on/off all lighting effects	Quick on/off all lighting effects
FN+Right Shift (long press)	Swap WASD and arrow keys	Swap WASD and arrow keys
FN+WIN	Win key lock	—
FN+1	F1	F1
FN+2	F2	F2
FN+3	F3	F3

FN+4	F4	F4
FN+5	F5	F5
FN+6	F6	F6
FN+7	F7	F7
FN+8	F8	F8
FN+9	F9	F9
FN+0	F10	F10
FN+-	F11	F11
FN++	F12	F12